



INSTRUCTION FOR

12-PIECE

MASTER CYLINDER ADAPTER SETS



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. PLEASE KEEP INSTRUCTIONS SAFE FOR FUTURE USE.

**ATTENTION !**

PLEASE WEAR PROTECTIVE EQUIPMENT SUCH AS EYE MASK, BREATHING MASK AND GLOVES WHEN EXTRACT OIL. BRAKE FLUID IS CORROSIVE. IF ANY FLUID SPILLS OUT, PLEASE FLUSH AWAY IMMEDIATELY.

SET INCLUDES

This Master Cylinder Adapter Set Includes Twelve Adapters All Designed To Work With Brake Fluid Bleeders, So You Can Easily Remove And Refill Fluid Into Your Entire Brake System On Your Own. Compatible With A Variety Of Master Cylinder Reservoirs, This Adapter Set Will Help You Get The Job Done On Nearly Any Brake System, whether You're A Professional Or A Diy-er.

1. Confirm The Interior Diameter Of The Master Cylinder Adapter Before Use.
2. Securely Attach Correct Adapter To Brake Fluid Bleeder Hose.
3. Follow Brake Fluid Bleeder Instructions For Removing And Replacing Brake Fluid From The Vehicle.



B
INNER DIA: 43MM
FOR TOYOTA AND LEXUS



B1
43.5MM
51.5MM
CHRYSLER, DODGE,
JEEP, AND PLYMOUTH



B2
43.5MM
51.5MM
CHRYSLER, DODGE,
JEEP, AND PLYMOUTH



B3
49.5MM
66.5MM
MOST MODEL GM CARS (BUICK,
CADILLAC, CHEVY, GMC, HUMMER,
OLDSMOBILE, PONTIAC) AND WITH
SOME MAZDA.



C1
50MM
79.5MM
HONDA ACCORD



C2
34.5MM
53.5MM
NISSAN



J
50.7MM
57MM
HYUNDAI, MITSUBISHI, NISSAN,
SUBARU, SOME CHRYSLER AND
DODGE, SOME FORD LINCOLN



E20
49MM
57MM
ALFA ROMEO, AUDI, BMW,
JAGUAR, LAND ROVER,
MERCEDES, PEUGEOT,
PORSCHE, RENAULT, SAAB,
VW, VOLVO, CHRYSLER
CROSSFIRE, DAEWOO,
LATE MODEL FORDS, KIA,
SOME MAZDA AND MINI



L
74MM
93MM
HONDA



E1
FOR CHRYSLER AND FOR GM



D1
47MM
UNIVERSAL



D2
29MM
UNIVERSAL