



5-Piece Master Cylinder Adapter Sets manual

Handbuch für 5-teilige Hauptbremszylinder-Adaptersätze



⚠ ATTENTION / HINWEIS



- Brake fluid is corrosive, please wear protective equipment such as eye mask, breathing mask and gloves. If any fluid spills out, please flush away immediately.
- Do not** allow children & untrained persons in the work area.
- When the operation is complete, **Do not** store the pressurized air in the tank as this will cause the tank to be deformed and damaged.
- Do not** exceed manufacturer's recommended pressure.

- Bremsflüssigkeit ist ätzend, bitte tragen Sie Schutzausrüstung wie Augenmaske, Atemmaske und Handschuhe. Wenn Flüssigkeit ausläuft, spülen Sie sie bitte sofort weg.
- Lassen Sie Kinder und ungeschulte Personen **nicht** im Arbeitsbereich.
- Wenn der Vorgang abgeschlossen ist, bewahren Sie die Druckluft **nicht** im Tank auf, da dies zu einer Verformung und Beschädigung des Tanks führt.
- Überschreiten Sie **nicht** den vom Hersteller empfohlenen Druck.

ADAPTER	COMPATIBLE	
Item NO.: A1 	Mitsubishi Nissan Gasoline Subaru Pronto Suzuki Volvo S40&V40	
Item NO.: A2 	Chrysler	All W/single three Prong Cap 1978-UP New Yorker All/Sebring 2001-UP/Stratus 1999-UP
	Dodge	All W/single three Prong Cap 1978-UP Stratus 1999-UP
	Dodge Truck	All W/single three Prong Cap 1978-UP
	Ford	All W/3 Twist-On Cap mid 80s and UP
	Ford Truck	All W/3 Twist-On Cap mid 80s and UP
	Hyundai	All W/3 Tap Cap All
	Jaguar	All W/3 Tap Cap All
	Infinity	All W/3 Tap Cap All
	Jeep	Cherokee 1995
	Kia	All W/3 Tap Cap All
	Lincoln	All W/3 Tap Twist-on Cap Mid 80s and UP
	Mazda	All W/3 Tap Twist-on Cap All
	Mercury	All W/3 Tap Twist-on Cap Mid 80s and UP
	Mitsubishi	All W/3 Tap Twist-on Cap All
	Nissan	All W/3 Tap Twist-on Cap All
	Plymouth	All W/single three Prong Cap 1978-UP Breeze All
	Saab	All W/3 Prong Twist-on Cap All
	Subaru	All W/3 Tap Twist-on Cap All
	Suzuki	Vitara/Grand/XL7 2001-UP
	Toyota	GT 86 2012-UP
Item NO.: T1 	Buick	All W/3 Tab Twist-on Cap Mid 1990s and UP
	Cadillac	All W/3 Tab Twist-on Cap Mid 1990s and UP
	Chevrolet	All W/3 Tab Twist-on Cap Mid 1990s and UP
	Ford	Fusion(Mondeo)All
	Mazda	Mazda 6 2003 UP/Rx8 2003 UP/MPV 2001 UP
	Oldsmobile	All W/3 Tab Twist-on Cap Mid 1990s and UP
	Pontiac	All W/3 Tab Twist-on Cap Mid 1990s and UP
	Saturn	All W/3 Tab Twist-on Cap Mid 1990s and UP
	Tesla	All W/3 Tab Twist-on Cap All

ADAPTER	COMPATIBLE	
Item NO.: A3 	Alfa Romeo	All W/45mm Threaded Cap All
	Aston Martin	DB7 Vantage All/DB7 Volante 2011-UP V8 Vantage 2011-UP/V12 Vanquish All
	Audi	All W/45mm Threaded Cap All
	Bentley	All W/45mm Threaded Cap All
	Bugatti	Veyron 2006-UP
	BMW	All W/45mm Threaded Cap All
	Chevrolet	Aveo 2007-2011/Cruze 2009-UP/Malibu 2012-UP
	Ferrari	All W/45mm Threaded Cap All
	Fiat	All W/45mm Threaded Cap Most
	Ford	Contour/Fiesta1978-1980/Focus/Mustang2005-UP
	Jaguar	All W/45mm Threaded Cap All
	Kia	All W/45mm Threaded Cap All
	Lamborghini	All
	Land Rover	All W/45mm Threaded Cap 1970-2001
	Mazda	All W/45mm Threaded Cap All
	Mecedes-Benz	All
	Mini	All
	Porsche	All W/45mm Threaded Cap All
	Renault	All W/45mm Threaded Cap All
	Suzuki	SX4 2006-2012/Splash 2007-UP/Swift 1996-UP
	Toyota	Corolla 2003-2009/Verso 2009-2014/Yaris 2006-2014
Item NO.: UNIVERSAL 	Volvo	All W/45mm Threaded Cap All
	VW	All W/45mm Threaded Cap All
	Acura	All 3" and Over ID Cap All
	Chevrolet	All W/metal Single Reservoir UP to 1970s
	Geo	All
	GMC	All W/metal Single Reservoir UP to 1970s
	Honda	All 3" and Over ID Cap All
	Hyundai	All Others All
	Infinity	All Others All
	Isuzu	All to 1989
	Jeep	All/Plastic Reservoir 1995-2001
	Kia	All Others All
	Range Rover	All Others All

	COMPATIBLE	
	Mitsubishi	All Others All
	Nissan	All Others All
	Peugeot	All
	Subaru	All Others All
	Toyota	Celica GT2.0/GT1600,CS2001-UP Cressida 1977-1981 Crown 1985-UP RAV4 1996-2009
	VW	1500/1600 Type 1,2,3 to 1988

Operation/Anleitung



1. Select the suitable adapter from Master Adapter Set
1. Passen den Adapter aus Master Adapter Set auswählen



2. Install adapter to the master cylinder of the brake system
and Pump the handle to bleed the fluid out of the system.
- 2.Installieren Sie den Adapter am Hauptzylinder des
Bremsystems und pumpen Sie den Griff, um die Flüssigkeit
aus dem System zu entlüften